





































































































Original		Replacement		Original		Replacement	
	Power		Power		Aspect		Format
	Text / Display		Text		Exit		Exit
	Call / Index		Info		Up / P+		Up
	1		1		Up / P+		Ch +
	2		2		Down / P-		Down
	3		3		Down / P-		Ch -
	4		4		Right / Vol +		Right
	5		5		Right / Vol +		Vol +
	6		6		Left / Vol -		Left
	7		7		Left / Vol -		Vol -
	8		8		OK		Ok
	9		9		Red		Red
	0		0		Green		Green
	Recall		Pre Ch		Yellow		Yellow
	Input		AV		Blue		Blue
	Menu / DVD		Menu		I/II		Dual
	→ [/] ←		3D		Audio		Shift + Dual





Original		Replacement		Original	Replacement
	Power		Power		
	Menu DVD		Menu		
	Up		Up		
	Down		Down		
	Right		Right		
	Left		Left		
	OK		Ok		
	Pause		Pause		
	Play		Play		
	<<		<<		
	>>		>>		
	Open/Close		Eject		
	Stop		Stop		
	I<<		I<<		
	>>I		>>I		



