






































































| Original   | Replacement   | Original  | Replacement  |
|--|---|---|--|
|  Power        |  Power   |  Prog-     |  Ch -           |
|  Open / Close |  Eject   |  Time Slip |  Sleep          |
|  Input Select |  AV      |  Info      |  Info           |
|  HDMI         |  Media   |  Text      |  Text           |
|  1            |  1       |  Audio     |  Dual           |
|  2            |  2       |  Subtitle  |  Subt           |
|  3            |  3       |  Guide     |  Guide          |
|  4            |  4       |  Top Menu  |  Menu           |
|  5            |  5       |  Disc Menu |  D. Menu        |
|  6            |  6       |  Up        |  Up             |
|  7           |  7      |  Left     |  Left          |
|  8          |  8     |  Enter   |  Ok           |
|  9          |  9     |  Right   |  Right        |
|  0          |  0     |  Down    |  Down         |
|  SAT Link   |  Smart |  Display |  Shift + Info |
|  Clear      |  Exit  |  Return  |  Back         |
|  Prog+      |  Ch +  |  Red     |  Red          |





| Original      | Replacement |
|---------------|-------------|
| Green         | Green       |
| Yellow / Mode | Yellow      |
| Blue / Search | Blue        |
| Blue / Search | TV/R        |
| << REV        | <<          |
| Play          | Play        |
| >> FWD        | >>          |
| I<< Skip      | I<<         |
| Stop          | Stop        |
| >>I Skip      | >>I         |
| Pause         | Pause       |
| VCR           | Vol +       |
| DVD           | Vol -       |
| Instant Skip  | 3D          |
| Dubbing       | Format      |
| Rec           | Rec         |
| Rec Mode      | Shift + Rec |

| Original       | Replacement   |
|----------------|---------------|
| Setup          | Options       |
| Timer Set      | Shift + Smart |
| Timer Prog     | Shift + Media |
| 1.3x/0.8x Play | Shift + Play  |

