






































































Original	Replacement	Original	Replacement
 Power	 Power	 Input	 AV / Input / RDS
 1	 1	 P+	 CH+ / Page+
 2	 2	 P-	 CH- / Page-
 3	 3	 [G=]	 Subtitle / EQ
 4	 4	 Info	 Info / Angle
 5	 5	 Back	 Back / Return
 6	 6	 Exit	 Exit / Cancel / Clear
 7	 7	 Up	 Up
 8	 8	 Down	 Down
 9	 9	 Left	 Left
 0	 0	 Right	 Right
 LANG.	 LANG. / I/II	 OK	 OK
 [=]	 Zoom / Size	 Netflix	 Shift + Red / Netflix /
 Home	 Shift + Home / Menu /	 FPlay	 Shift + Blue / Prime
 Vol+	 Vol+	 Menu	 Menu / Home
 Vol-	 Vol-	 Youtube	 Shift + Yellow / YouTube /
 Mute	 Mute / Dimmer	 <<	 << / Tune-



