

































| Original | Replacement |
|--|--|
|  Standby |  Power |
|  Mute |  Mute |
|  Source |  AV |
|  P.Mode |  Shift + Format |
|  S.Mode |  Shift + Dual |
|  Audio I/II |  Dual |
|  Sleep |  Sleep |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  4 |  4 |
|  5 |  5 |
|  6 |  6 |
|  7 |  7 |
|  8 |  8 |
|  9 |  9 |
|  0 |  0 |

| Original | Replacement |
|---|---|
|  Recall |  Shift + Guide |
|  Menu |  Pre Ch |
|  Exit |  Menu |
|  Text |  Exit |
|  Display |  Text |
|  Up |  Info |
|  Down |  Up |
|  Right |  Down |
|  Left |  Right |
|  OK |  Left |
|  Vol+ |  Ok |
|  Vol- |  Vol + |
|  CH+ |  Vol - |
|  CH- |  Ch + |
|  Red |  Ch - |
|  Green |  Red |
| |  Green |





| Original | | Replacement | | Original | | Replacement | |
|---|-------------|---|---------|---|---------|---|----|
|  | Yellow |  | Yellow |  | <</FAV- |  | << |
|  | Blue |  | Blue |  | >>/FAV+ |  | >> |
|  | Subtitle |  | Subt | | | | |
|  | Size |  | Format | | | | |
|  | Reveal |  | Back | | | | |
|  | Mix |  | Smart | | | | |
|  | Index |  | List | | | | |
|  | EPG |  | Guide | | | | |
|  | Media |  | Media | | | | |
|  | Timeshift |  | Options | | | | |
|  | Tv/Radio |  | TV/R | | | | |
|  | Play |  | Play | | | | |
|  | Pause/Hold |  | Pause | | | | |
|  | Rec |  | Rec | | | | |
|  | Stop/FAV |  | Stop | | | | |
|  | I<</Cancel |  | I<< | | | | |
|  | >>I/Subpage |  | >>I | | | | |

