

















Original	Replacement
 Power	 Power
 Title	 Options
 Subtitle	 Subt
 SCR Size	 Format
 Angle	 Red
 Repeat	 Text
 A-B Repeat	 Green
 BRT Cont.	 Blue
 Device	 Yellow
 Menu	 Menu
 Setup	 D. Menu
 Info	 Info
 Search	 TV/R
 Audio	 Dual
 Movie	 Shift + 1
 Tv Out	 AV
 Music	 Shift + 2

Original	Replacement
 Photo	 Shift + 3
 All Media	 Shift + 4
 ←Slow	 Back
 Stop	 Stop
 Play	 Play
 Pause	 Pause
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 Ok
 >>	 >>
 <<	 <<
 >>	 >>
 <<	 <<
 1/Select	 1
 2/Select All	 2





	Original	Replacement		Original	Replacement
	3		3		
	4		4		
	5		5		
	6		6		
	7		7		
 REFRESH	8/Refresh		8		
	9		9		
 SLEEP	0/Sleep		0		
 BOOKMARK	./ Bookmark		GUIDE		
 MUTE	Mute		MUTE		
	Vol+		VOL +		
	Vol-		VOL -		

