




























































Original	Replacement
 POWER	 Power
 SLEEP	 Sleep / Timer
 6 CH. INPUT	 AV / Input / RDS
 DVD	 Shift + 2
 D-TV / CBL	 2
 VCR	 4
 V-AUX	 7
 CD	 3
 TUNER	 6
 MD / CD-R	 9
 TUNER - PRESET-	 CH- / Page-
 TUNER - PRESET+	 CH+ / Page+
 TUNER - A	 Red / Netflix / Search
 TUNER - B	 Green / APP / Repeat
 TUNER - C	 Yellow / YouTube / Repeat
 TUNER - D	 Blue / Prime Video / Random
 TUNER - E	 Setup / OPT /

Original	Replacement
 HALL	 0
 JAZZ CLUB	 1
 ROCK CONCERT	 Sound / Title
 ENTERTAINMEN	 Smart / List
 TV SPORTS	 Shift + 1
 MONO / MOVIE	 Picture / Format
 MOVIE THEATER -	 5
 MOVIE THEATER -	 8
 DOLBY / DST SUR.	 Eject / Surround
 MATRIX 6.1	 Guide / EPG / -/--
 SELECT	 OK
 LEVEL	 Display / Media
 UP	 Up
 SET MENU	 Menu / Home
 -	 Left
 +	 Right
 TEST	 Text / Goto



