














































| Original   | Replacement   |
|--|---|
|  Power  |  Power               |
|  Mute   |  Mute / Dimmer       |
|  1      |  1                   |
|  2      |  2                   |
|  3      |  3                   |
|  4      |  4                   |
|  5      |  5                   |
|  6      |  6                   |
|  7      |  7                   |
|  8      |  8                   |
|  9     |  9                  |
|  0    |  0                 |
|  EPG  |  Guide / EPG / -/- |
|  Rec  |  Rec / Rec Mode    |
|  Info |  Info / Angle      |
|  Vol+ |  Vol+              |
|  Vol- |  Vol-              |

| Original   | Replacement   |
|--|---|
|  CH+          |  CH+ / Page+                   |
|  CH-          |  CH- / Page-                   |
|  ≡            |  D.Menu / Top                  |
|  Input        |  AV / Input / RDS              |
|  Smart Colors |  Display / Media               |
|  Up           |  Up                            |
|  Down         |  Down                          |
|  Right        |  Right                         |
|  Left         |  Left                          |
|  OK           |  OK                            |
|  Back        |  Back / Return                |
|  EXIT       |  Exit / Cancel / Clear       |
|  Red        |  Red / Netflix / Search      |
|  Home       |  Menu / Home                 |
|  Green      |  Green / APP / Repeat        |
|  Yellow     |  Yellow / YouTube / Repeat   |
|  Blue       |  Blue / Prime Video / Random |





| Original  | Replacement | Original  | Replacement                |
|---|-------------|---|----------------------------|
|    | <<          |    | << / Tune-                 |
|    | >>          |    | >> / Tune+                 |
|    | Play        |    | Play / Slow                |
|    | Pause       |    | Pause / Step / Freeze      |
|    | Stop        |    | Stop / Hold                |
|    | Subt        |    | Subtitle / EQ              |
|    | Audio       |    | Audio / Lang I/II          |
|    | TXT         |    | Text / Goto                |
|    | Netflix     |    | Shift + Red / Netflix /    |
|   | YouTube     |   | Shift + Yellow / YouTube / |
|  | prime video |  | Shift + Blue / Prime       |
|  | Google Play |  | Shift + Green / APP /      |
|   |             |   |                            |
|   |             |   |                            |
|   |             |   |                            |
|   |             |   |                            |
|   |             |   |                            |
|   |             |   |                            |
|   |             |   |                            |
|   |             |   |                            |
|   |             |   |                            |
|   |             |   |                            |
|   |             |   |                            |
|   |             |   |                            |

