







































































Original		Replacement		Original		Replacement	
	Power		Power		MTS		Media
	Mute		Mute		Menu		Menu
	1		1		Source		AV
	2		2		Exit		Exit
	3		3		Display		Info
	4		4		Up		Up
	5		5		Down		Down
	6		6		Right		Right
	7		7		Left		Left
	8		8		Enter		Ok
	9		9		Vol+		Vol +
	0		0		Vol-		Vol -
	ATV/DTV		D. Menu		Rec		Rec
	Recall		Back		Rec List		List
	P.Mode		Format		Tv/Radio		TV/R
	S.Mode		Dual		FAV List		Pre Ch
	Sleep		Sleep		CH+		Ch +





Original		Replacement		Original		Replacement	
	CH-		Ch -		Cyan		Blue
	Play		Play				
	Pause/Time Shift		Pause				
	<</Guide		<<				
	>>/Aspect		>>				
	Stop/Index		Stop				
	I<</Cancel		I<<				
	>>I/Sub.PG		>>I				
	Freeze		Eject				
	Subtitle		Subt				
	Size		3D				
	Reveal		Options				
	Hold		Smart				
	Text		Text				
	Red		Red				
	Green		Green				
	Yellow		Yellow				

