Mandis shop

LaCie LACINEMAPLAYHD

Original	Replacement
POWER	Power
HOME	Smart
SKIP PREV.	I<<
SKIP NEXT	>>I
PLAY	Play
PAUSE	Pause
STOP	Stop
EJECT	Eject
FWD	>>
REW	<<
BACK	Back
FAV	Pre Ch
INFO	Info
SETTINGS	Options
UP	Up
DOWN	Down
RIGHT	Right

Original	Replacement
LEFT	Left
OK	Ok
VOL+	Vol +
VOL-	Vol -
MUTE	Mute
SEARCH	TV/R
PAGE UP	Ch +
PAGE DOWN	Ch -

https://all-remote-controls.co.uk/en/LaCie/1055483-20309-replacement-remote-control-for-LaCie-2000274.html