Mandis shop

Philips 996580004618

Original		Replacement	
	Power		Power
AUDIO IN	Audio In	A	Red
USB	USB	B	Green
COAX	Coax	C	Yellow
AUX	AUX	D	Blue
OPT	OPT	SETTINGS OPT	Options
REPEAT	Repeat	REPEAT TEXT	Text
	Play	PLAY MODE	Play
	Pause		Pause
	>I		>>I
	I<		I<<
VOL +	Vol+	VOL +	Vol +
VOL −	Vol-	VOL −	Vol -
	Mute	MUTE	Mute
AUDIO SYNC +	Audio Sync+	CH +	Ch +
AUDIO SYNC −	Audio Sync-	CH −	Ch -
BASS +	Bass+		Up

Original		Replacement	
BASS −	Bass-		Down
TREBLE +	Treble+		Right
TREBLE −	Treble-		Left
SURR	Surr	HOME SMART	Smart
NIGHT	Night	APP MEDIA	Media

https://all-remote-controls.co.uk/en/Philips/1055710-65999-replacement-remote-control-for-Philips-996580004618.html