Mandis shop

BOSE CINEMATE GS SERIES II

Original		Replacement		Original		Replacement	
On Off	On/Off		Power				
TV-Video	TV-Video	PROGRAM TV/RADIO	TV/Radio /				
Mute	Mute	DIMMER MUTE	Mute / Dimmer				
TV	TV	TV 1	1				
CBL SAT	CBL/SAT	HDMI - SAT 0	0				
DVD	DVD	DVD 2	2				
VCR	VCR	VIDEO 4	4				
AUX	AUX	AUX - HDD 7	7				
+ Volume	Volume +	+ VOL	Vol+				
- Volume	Volume -	VOL -	Vol-				
Setup	Setup	OPT-TOOLS SETUP	Setup / OPT /				
Setup	Setup	HOME MENU	Menu / Home				

https://all-remote-controls.co.uk/en/BOSE/1056290-48787-replacement-remote-control-for-BOSE-CineMate-GS-SeriesII.html