Mandis shop

JBL001

Original		Replacement	
	+		Right
	+	V+	V+
	-	V-	V-
	-		Left
	Mute		Mute
	>	BAND	Play / Band
	<<	SLOW	<<
	>>	STEP	>>
	Down		Down
	Up		Up
MENU	Menu	2 MENU	2 / Menu
	←I	OK	OK

Original	Replacement

https://all-remote-controls.co.uk/en/JBL/1056457-90665-replacement-remote-control-for-JBL-JBL001.html