Mandis shop

Sharp RRMCGA024SJSA

Original	Replacement
On/Standby	Power
Timer	AV
Clock	3D
Memory	Ok
Clear	Exit
Random/Repeat	Text
Sleep	Sleep
Display	Info
CD	Yellow
Tuner/Band	Green
Tape	Red
Video/AUX	Blue
>>/Tuning Up	>>
<</Tuning	<<
>>I/Preset Up	>>I
I<</Preset	I<<
Play	Play

Original	Replacement
Stop	Stop
Pause	Pause
1/Memory	1
2/Clear	2
3/Random/Repe	3
4/Clock	4
5/Timer	5
6/Sleep	6
7	7
8	8
9	9
0	0
+10	Guide
Shift	Media
Treble/Bass	Smart
Vol+	Vol +
Vol-	Vol -

https://all-remote-controls.co.uk/en/Sharp/1057750-82546-replacement-remote-control-for-Sharp-RRMCGA024SJSA.html