Mandis shop

Iomega SCREENPLAY-MX2HD

Original	Replacement	Original	Replacement
Power	Power	Eject	Eject
Home	Smart		
Up	Up		
Down	Down		
Right	Right		
Left	Left		
Enter	Ok		
Back	Back		
Option	Options		
Stop	Stop		
Pause	Pause		
Play	Play		
<<	<<		
>>	>>		
>>I/Next	>>I		
I<<Prev	I<<		
Search	TV/R		

https://all-remote-controls.co.uk/en/Iomega/1058892-20600-replacement-remote-control-for-Iomega-Screenplay-MX2-HD.html