Mandis shop

Epson 1500151

Original	Replacement
Power	Power
HDMI1	Vol + / Page +
HDMI2	- / Stop
Component	Comp / Video
PC	3D / Invert
S-Video	Vol - / Page -
Default	Shift + Power
Video	Shift + Comp / Video
Menu	Menu
Esc	Mode
Up	Up
Down	Down
Right	Right
Left	Left
Enter/Line Menu	Enter
Memory	Source
Aspect	Eco / Aspect

Original	Replacement
RGBCMY	Volt / Focus
Gamma	Auto
Color Mode	Help / Info
Sharpness	+ / Play
Pattern	Freeze / Timer
Blank	Blank / Mute

https://all-remote-controls.co.uk/en/Epson/1060092-66075-replacement-remote-control-for-Epson-150015101-1500151.html