Original		Replacement	
Power		Power	
1		1	
2		2	
3		3	
4		4	
5		5	
6		6	
7		7	
8		8	
9		9	
0		0	
Lang		Dual	
TXT		Text	
V+		Vol +	
V-		Vol -	
Mute		Mute	
Source		AV	

Original		Replacement	
P+		Ch +	
P-		Ch -	
Home		Smart	
G		Guide	
i		Info	
Back		Back	
Exit		Exit	
Up		Up	
Down		Down	
Right		Right	
Left		Left	
OK		Ok	
Netflix		Media	
YouTube		Shift + Smart	
FPay		Shift + Media	
☼1		Format	
Red		Red	

Original		Replacement	
	Green	B	Green
	Yellow	C	Yellow
	Blue	D	Blue
	<<		<<
	Pause		Pause
	>>		>>
	Rec	REC MODE	Rec
	Play	PLAY MODE	Play
	Stop		Stop

Original	Replacement