Mandis shop

Sanyo CXWF

Original	Replacement
Power	Power
Computer	Comp / Video
Video	Shift + Comp / Video
Menu	Menu
Keystone	Shift + Up
Up	Up
Down	Down
Right	Right
Left	Left
Vol+	Vol + / Page +
Vol-	Vol - / Page -
Select	Enter
D.Zoom+	+ / Play
D.Zoom-	- / Stop
Auto PC	Auto
Image	Eco / Aspect
Freeze	Freeze / Timer

Original	Replacement
P-Timer	Shift + Freeze / Timer
No Show	Source
Mute	Blank / Mute
Lamp Control	3D / Invert

https://all-remote-controls.co.uk/en/1063236-21665-replacement-remote-control-for-Sanyo-CXWF-6450909498.html