Mandis shop

# JVC RM-SUXP5R




| Original | Replacement |
|---|---|
| Standby / On | Power |
| MD/AUX | Red |
| FM/AM | Green |
| Tape <> | Blue |
| Play/Pause CD | Play |
| Play/Pause CD | Pause |
| Play/Pause CD | Yellow |
| Dimmer | Smart |
| Display | Info |
| Sleep | Sleep |
| Prog | Shift + Sleep |
| Random | Media |
| Repeat | Text |
| Sound Mode | Dual |
| FM Mode | TV/R |
| Auto Preset | List |
| I<< | I<< |

| Original | Replacement |
|---|---|
| Stop | Stop |
| >>I | >>I |
| Cancel | Exit |
| < Multi Key | Left |
| CD Eject | Pre Ch |
| Multi Key > | Right |
| Set | Menu |
| Display Mode | Format |
| PTY/EON | AV |
| AHB Pro | Subt |
| Volume+ | Vol + |
| Volume- | Vol - |

https://all-remote-controls.co.uk/en/JVC/1063380-79072-replacement-remote-control-for-JVC-RM-SUXP5R.html