Mandis shop

MA06TS8TSPN18

Original		Replacement	
	Power		Power
	Night	CLEAR EXIT	Exit
SURR	Surr	AD SUBT	Subt
OPT	OPT	SETTINGS OPT	Options
HDMI IN	HDMI In	HOME SMART	Smart
HDMI ARC	HDMI ARC	APP MEDIA	Media
USB	USB	C	Yellow
AUX	AUX	A	Red
	Bluetooth/Pairing	B	Green
MOVIE	Movie	D	Blue
MUSIC	Music	SOUND DUAL	Dual
TV	TV	SEARCH TV/R	TV/R
TREBLE	Treble+	+ CH	Ch +
TREBLE	Treble-	CH −	Ch -
BASS	Bass+	+ VOL	Vol +
BASS	Bass-	VOL −	Vol -
	Mute	MUTE	Mute

Original		Replacement	
	Up		Up
	Down		Down
	Right		Right
	Left		Left
OK	OK	OK	Ok
OK	Play	PLAY MODE	Play
OK	Pause		Pause

https://all-remote-controls.co.uk/en/Tcl/1063636-94426-replacement-remote-control-for-Tcl-RC1-MA06TS8TSPN18.html