Mandis shop

Pioneer CU-XC005

Original	Replacement
Direct Play (--)	Red / Netflix / Search
Direct Play OO	Green / APP / Repeat
Direct Play Y	Yellow / YouTube / Repeat
Direct Play [*]	Blue / Prime Video / Random
Menu	Menu / Home
Sound	Sound / Title
>>	>> / Tune+
Timer	Sleep / Timer
Cancel	Exit / Cancel / Clear
I<</-	I<< / Preset-
Stop	Stop / Hold
>>I/+	>>I / Preset+
Set	Setup / OPT /
Display/Character	Info / Angle
<<	<< / Tune-
AUX	7
Display Down	CH- / Page-

Original	Replacement
Display Up	CH+ / Page+
Power	Power
Vol-	Vol-
Vol+	Vol+

https://all-remote-controls.co.uk/en/Pioneer/1065991-5307-replacement-remote-control-for-Pioneer-CU-XC005-AXD7170.html