Mandis shop

Pioneer CU-XC004

Original	Replacement
Direct Play (--)	Red / Netflix / Search
Direct Play OO	Green / APP / Repeat
Direct Play Y	Yellow / YouTube / Repeat
Direct Play [*]	Blue / Prime Video / Random
Menu	Menu / Home
>>	>> / Tune+
Cancel	Exit / Cancel / Clear
I<</-	I<< / Preset-
Stop	Stop / Hold
>>I/+	>>I / Preset+
Set	Setup / OPT /
<<	<< / Tune-
AUX	7
Sound	Sound / Title
Display	Display / Media
Power	Power
Volume-	Vol-

Original	Replacement
Volume+	Vol+

https://all-remote-controls.co.uk/en/Pioneer/1066307-5309-replacement-remote-control-for-Pioneer-CU-XC004-AXD7145.html