Mandis shop

RMT-812

Original	Replacement	Original	Replacement
Photo	Smart / List	<|<II	Left
Zero Set	Setup / OPT /	Stop	Stop / Hold
Start/Stop	Power	>/II>	Right
Display	Display / Media	Pause	Pause / Step / Freeze
Data Code	Menu / Home	Slow I>	Sleep / Timer
T	Up	X2	Zoom / Size
Play Memory	Exit / Cancel / Clear	Mark	Fav / Marker / PC
Index Memory	Info / Angle	Audio Dub	Audio / Lang I/II
Memory-	Vol-		
Memory+	Vol+		
W	Down		
Search Mode	Red / Netflix / Search		
I<<	I<< / Preset-		
>>I	>>I / Preset+		
<<	<< / Tune-		
Play	Play / Slow		
>>	>> / Tune+		

https://all-remote-controls.co.uk/en/Sony/1066699-81366-replacement-remote-control-for-Sony-RMT-812-147595031.html