Mandis shop

RC-858

Original	Replacement	Original	Replacement
Power	Power		
Muting	Mute / Dimmer		
Track >>I	>>I / Preset+		
Function Up	CH+ / Page+		
Volume Up	Vol+		
I<< Track	I<< / Preset-		
Function Down	CH- / Page-		
Volume Down	Vol-		
Pause	Pause / Step / Freeze		
Stop	Stop / Hold		
Play	Play / Slow		

https://all-remote-controls.co.uk/en/Denon/1059630-86421-replacement-remote-control-for-Denon-RC-858-00D3990523005.html