Original		Replacement	
POWER	Power		Power
SLEEP	Sleep	PROG SLEEP	Sleep
CBL/SAT	CBL/SAT	1	1
DVD	DVD	2	2
Blu-ray	Blu-ray	3	3
GAME	Game	4	4
AUX	AUX	5	5
iPod/USB	iPod/USB	6	6
TV AUDIO	Tv Audio	7	7
FM	FM	8	8
NETWORK	Network	9	9
INTERNET RADIO	Internet Radio	SEARCH TV/R	TV/R
CHANNEL	Channel+	+ CH	Ch +
CHANNEL	Channel-	CH –	Ch -
PAGE	Page Up	AD SUBT	Subt
PAGE	Page Down	SOUND DUAL	Dual
MOVIE	Green/Movie	B	Green

Original		Replacement	
SOUND MUSIC	Red/Music	A	Red
MODE GAME	Blue/Game	D	Blue
PURE	Yellow/Pure	C	Yellow
INFO	Info	DISPLAY INFO	Info
OPTION	Option	SETTINGS OPT	Options
BACK	Back	RETURN BACK	Back
SETUP	Setup	TOP MENU MENU	Menu
	Up		Up
	Down		Down
	Right		Right
	Left		Left
ENTER	Enter	OK	Ok
VOLUME	Volume+	+ VOL	Vol +
VOLUME	Volume-	VOL –	Vol -
MUTE	Mute	MUTE	Mute
FAV 1	Favorite Station 1	REPEAT TEXT	Text
FAVORITE STATION 2	Favorite Station 2	TIMER AV	AV

Original		Replacement	
	Favorite Station 3		Format
	I<<</Tune-		I<<
	Tune+/>>I		>>I
	Play		Play
	Pause		Pause

Original	Replacement