Mandis shop

RM-SRCBX330A

Original	Replacement	Original	Replacement
Play	Play / Slow		
Pause	Pause / Step / Freeze		
Stop	Stop / Hold		
Skip/Search	>>I / Preset+		
I<<	I<< / Preset-		
Program	TV/Radio /		
Repeat	Green / APP / Repeat		

https://all-remote-controls.co.uk/en/JVC/1067259-91959-replacement-remote-control-for-JVC-RM-SRCBX330A.html