Mandis shop

LG AKB75595342

Original		Replacement	
	Power		Power
VOL +	Vol +	VOL +	Vol +
VOL —	Vol -	VOL —	Vol -
	Mute	MUTE	Mute
F	F	TOP MENU MENU	Menu
	I <<		I <<
	Play	PLAY MODE	Play
	Pause		Pause
	>>I		>>I
SOUND EFFECT	Sound Effect	SOUND DUAL	Dual
	Equalizer	SETTINGS OPT	Options
	i	DISPLAY INFO	Info
REPEAT	Repeat	REPEAT TEXT	Text
FOLDER/PRESET	Folder/Preset Up	CH +	Ch +
FOLDER/PRESET	Folder/Preset	CH —	Ch -
	Night	PROG SLEEP	Sleep
PRESET DELETE	Preset Delete	CLEAR EXIT	Exit

Original		Replacement	
PTY	PTY	APP MEDIA	Media

https://al-remotecontrols.co.uk/product/lg-akb75595342-replacement-remote-control-for-lg-akb75595342/