Mandis shop

LG AKB75855505

Original		Replacement	
	Power		Power
	Power Sources	SEARCH TV/R	TV/R
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0 QUICK ACCESS	0	0	0
-/ LIST	List	DISC NAV LIST	List
AD/SAP	AD/SAP	SOUND DUAL	Dual
	Mute	MUTE	Mute
	Micro	APP MEDIA	Media
	Vol+	+ VOL	Vol +

Original		Replacement	
	Vol-	VOL –	Vol -
	CH+	+ CH	Ch +
	CH-	CH –	Ch -
	Home	HOME SMART	Smart
	☼	TOP MENU MENU	Menu
	Up		Up
	Down		Down
	Left		Left
	Right		Right
	OK	OK	Ok
	Weel Up	>>I	
	Weel Down	I<<	
	Back	RETURN BACK	Back
GUIDE	Guide	-/-- GUIDE	Guide
NETFLIX	Netflix	SHIFT + APP MEDIA	Shift + Media
	Source	TIMER AV	AV
prime video	prime video	PROG SLEEP	Sleep

Original		Replacement	
	Red	A	Red
	Green	B	Green
	Yellow	C	Yellow
	Blue	D	Blue
MOVIES	Movies	ECO 3D	3D
	Play	PLAY MODE	Play
	Pause		Pause

Original	Replacement