Mandis shop

Maxell MXSP-SB3000

Original		Replacement	
	POWER		Power
	DIM		Info
	OPT		5
	MUTE		Mute
	SRS		AV
	HDMI 1		1
	HDMI 2		2
	HDMI 3		3
	ARC		4
	OPT		Options
	COAX		6
	LINE IN 1		7
	LINE IN 2		8
	BT		9
	PAIR		0
	VOL+		Vol +
	VOL+		Up

Original		Replacement	
	VOL -		Vol -
	VOL -		Down
	SKIP NEXT		Right
	SKIP NEXT		Ch +
	SKIP PREV.		Left
	SKIP PREV.		Ch -
	PLAY / PAUSE		Ok
	BASS		Dual
	PLAY / PAUSE		Play
	PLAY / PAUSE		Pause
	SKIP NEXT		>>
	SKIP NEXT		>>I
	SKIP PREV.		<<
	SKIP PREV.		I<<
	EQ		Smart

https://all-remote-controls.co.uk/en/Maxell/1063061-79790-replacement-remote-control-for-Maxell-MXSP-SB3000.html