Mandis shop

Panasonic N2QAYC000079

Original		Replacement	
	Power		Power
SLEEP	Sleep	PROG SLEEP	Sleep
DIMMER	Dimmer	HOME SMART	Smart
iPod/USB	iPod/USB	1	1
CD	CD	2	2
RADIO	Radio	3	3
⏮/◀◀	<<	◀◀	<<
⏮/◀◀	I <<	⏮	I <<
▶/II	Play	PLAY MODE ▶	Play
▶/II	Pause	II	Pause
▶▶/⏭	>>I	⏭	>>I
▶▶/⏭	>>	▶▶	>>
■	Stop	■	Stop
VOL−	Vol -	VOL −	Vol -
VOL+	Vol +	+ VOL	Vol +
SETUP	Setup	SETTINGS OPT	Options
MUTE	Mute	MUTE	Mute

Original		Replacement	
iPod MENU DISPLAY	Display/iPod	TOP MENU MENU	Menu
SOUND	Sound	SOUND DUAL	Dual
PLAY MENU	Play Menu	E-MANUAL D.MENU	D. Menu
▼	Album Down	▼	Down
OK	OK	OK	Ok
▲	Album Up	▲	Up

https://al-remotecontrols.co.uk/Panasonic/1630257-replacement-remote-control-for-Panasonic-N2QAYC000079.htm