Mandis shop

# Panasonic N2QAYC000103

| Original | | Replacement | |
|---|---|---|---|
| POWER | Power | POWER | Power |
| SURROUND | Surround | SOUND DUAL | Dual |
| CLEAR VOICE | Clear/Voice | CLEAR EXIT | Exit |
| + SUBWOOFER | Subwoofer+ | + CH | Ch + |
| SUBWOOFER − | Subwoofer- | CH − | Ch - |
| + VOL | Vol+ | + VOL | Vol + |
| VOL − | Vol- | VOL − | Vol - |
| MUTE | Mute | MUTE | Mute |
| TV | TV | SEARCH TV/R | TV/R |
| BD/DVD | BD/DVD | APP MEDIA | Media |
| -PAIRING | Bluetooth-Pairing | HOME SMART | Smart |

| Original | Replacement |
|---|---|
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

https://all-remote-controls.co.uk/en/Panasonic/1064337-24167-replacement-remote-control-for-Panasonic-N2QAYC000103.html