Mandis shop

BN59-01376A

Original	Replacement	Original	Replacement
Power	Power	EPG	Guide / EPG / -/--
123	1		
Colors	Smart / List		
Up	Up		
OK	OK		
Down	Down		
Right	Right		
Left	Left		
Back	Back / Return		
Home	Menu / Home		
Play	Play / Slow		
Pause	Pause / Step / Freeze		
Vol+	Vol+		
Vol-/CC/VD	Vol-		
Mute	Mute / Dimmer		
CH+	CH+ / Page+		
CH-	CH- / Page-		

https://all-remote-controls.co.uk/en/Samsung/1066639-96091-replacement-remote-control-for-Samsung-BN59-01376A.html