Mandis shop

REMCON2089



Original		Replacement		Original	Replacement
STANDBY	Standby		Power		
BLUETOOTH	Bluetooth	BLUETOOTH 9	9		
PREVIOUS	Previous	PRESET-	I<< / Preset-		
NEXT	Next	PRESET+	>>I / Preset+		
PLAY/PAUSE	Play	SLOW	Play / Slow		
PLAY/PAUSE	Pause	STEP-FREEZE	Pause / Step / Freeze		
AUX 1	AUX 1	TV 1	1		
AUX 2	AUX 2	DVD 2	2		
OPTICAL	Optical	CD-STB 3	3		
LOUD	Loud	LIST SMART	Smart / List		
VOLUME –	Volume-	VOL –	Vol -		
VOLUME +	Volume+	+ VOL	Vol +		
	E2	Prime Video RANDOM	Blue / Prime Video / Random		
	A2	NETFLIX SEARCH	Red / Netflix / Search		
	C2	APP REPEAT	Green / APP / Repeat		
	D2	YouTube REPEAT A-B	Yellow / YouTube / Repeat		

https://al-remotecontrols.co.uk/Sansonic/1034954-replacement-remote-control-for-Sansonic-REMCON2089.htm