Mandis shop

HT-SBW800

Original		Replacement		Original	Replacement
	Power		Power		
	Bluetooth	TOP MENU MENU	Menu		
	Source	TIMER AV	AV		
SURR	Surr	SOUND DUAL	Dual		
HDMI	HDM	HOME SMART	Smart		
+	Vol +	+ VOL	Vol +		
–	Vol -	VOL –	Vol -		
	Mute	MUTE	Mute		
	>>I		>>I		
	I <<		I <<		
	Play	PLAY MODE	Play		
	Pause		Pause		
BASS +	Bass+		Up		
BASS –	Bass-		Down		
EQ	EQ	APP MEDIA	Media		
TRE +	Tre+	+ CH	Ch +		
TRE –	Tre-	CH –	Ch -		

https://al-remotecontrols.co.uk/Sharp/1661-932-replacement-remote-control-for-Sharp-HT-SBW800.htm