Mandis shop

Sony RMT835

Original	Replacement
Photo	Smart / List
Data Code	Back / Return
Star/Stop	Power
<<< / ◁ Scan	<< / Tune-
Scan Slow	>> / Tune+
T	CH+ / Page+
I <<	I << / Preset-
>>I	>>I / Preset+
Play	Play / Slow
Pause	Pause / Step / Freeze
W	CH- / Page-
Stop	Stop / Hold
Up	Up
Visual Index	Info / Angle
Left	Left
Enter	OK
Right	Right

Original	Replacement
Display	Display / Media
Down	Down

https://al-remotecontrols.co.uk/Sony/1673-780-replacement-remote-control-for-Sony-RMT835-147275.html