Mandis shop

Toshiba CT-8529

Original	Replacement
Power	Power
Vol +	Vol +
Vol -	Vol -
Home	Smart
P+	Ch +
P-	Ch -
Guide	Guide
Input	AV
Back	Back
Exit	Exit
Up	Up
Down	Down
Right	Right
Left	Left
OK	Ok
Colors	Red
Play	Play

Original	Replacement
Stop	Stop
123#	Pre Ch
Rakuten Tv	TV/R
Netflix	Media
YouTube	Shift + Media

https://al-remotecontrols.co.uk/Toshiba/1587-850-replacement-remote-control-for-Toshiba-CT-8529.html