Mandis shop

TRAVELHD

Original		Replacement	
	Power		Power
	Home	HOME SMART	Smart
	X	TIMER AV	AV
MENU	Menu	TOP MENU MENU	Menu
EDIT	Edit	CLEAR EXIT	Exit
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	Enter	OK	Ok
INFO	Info	DISPLAY INFO	Info
PLAY/PAUSE	Play	PLAY MODE	Play
PLAY/PAUSE	Pause		Pause
STOP	Stop		Stop
FR	<</FR		<<
FF	>>/FF		>>
PREV	I<</Prev		I<<

Original		Replacement	
NEXT	>>I/Next		>>I
ZOOM	Zoom	ZOOM	Eject
VOL+	Vol+	VOL +	Vol +
VOL-	Vol-	VOL -	Vol -
	Mute	MUTE	Mute

https://all-remote-controls.co.uk/en/WE/1058570-90734-replacement-remote-control-for-WE-Travel-HD-1T-Travel-HD.html