Mandis shop

WOX001

Original		Replacement	
	Up		Up
	Left		Left
OK	OK	OK	OK
	Right		Right
	Down		Down
	Home	HOME MENU	Menu / Home
	Back	RETURN BACK	Back / Return
VOL	Vol+	VOL	Vol+
	[■]	OPT-TOOLS SETUP	Setup / OPT /
VOL	Vol-	VOL	Vol-
	Power		Power

Original	Replacement

https://all-remote-controls.co.uk/en/Woxter/1067303-79404-replacement-remote-control-for-Woxter-WOX001.html